

Main new feature list

1. Full support for all modules with FLASH chip.
2. Network support for Windows 9X, NT, 2K, XP SP1/2 and 2K Server.
3. Full support for the Tank Control Modules TCM100 and TCM200.
TCM100 = Pump control and Discrete (Switch) 1 or 2 levels sensor.
TCM200 = Pump control, Discrete (Switch) 1 or 2 levels sensor and Analogue level sensor.
4. Wildcard job number validation both printer module and PC database.
5. Dual/Quadra pulse count for increased accuracy.
6. Cyclic dispense mode that can be used for central lubrication.
7. Auto generated warning layout for modules in warning status such as tanks with low level.
8. Sphere support, can be used for having reels with the same fluid have the same number in different reel bays.
9. Improved language support.
10. Improved Preset handling added to WinDB Manager.
11. Advanced Tank Control Module support added to WinDB Manager.
12. Engine supports extended logging for flash chip technology.
13. New "Update PNP Array" layout with added information.
14. New reports and Views added to WinDB Manager.
15. Enhanced DMS connection support.

Observe !

16. The PC database has been enhanced. This means that for an update your present database (before R7) must be updated to match LMWT 8 .
17. To update first make a backup of the present LUBE-Master folder, especially the files license.dat and LubeMasterDB.mdb. Then uninstall LUBE-Master WinDB Manager. Then uninstall LUBE-Master software. Then delete the c:\lubemast folder if it still exists. Now install the version 8 software. Check the ReadMe.txt file first. Update your old database to look like the R7 one and then put it in the c:\lubemast folder
18. Manuals on CD are not updated with version 8 features yet.

May 2007