


LUBE-Master



**DMS /
ERP**



DRIVER AAS DMS LUBE-MASTER

DRIVER AAS DMS LUBE-MASTER

Data connection to LUBE-Master, for validation of job no before refilling. After the job done, transfer the information about job number, volume and part no to the system.

TECHNICAL DATA

Part No	53586
H.S. Code	85176200



EUROLUBE EQUIPMENT

by Alentec & Orion AB, Grustagsvägen 4, SE-138 40 Älta, Sweden

EMAIL *eurolube@alentec.se

PHONE +46 (0)8-747 67 10

FAX +46 (0)8-715 20 74

 www.eurolube.com